

PULUZ PU 5060EU

Instrukcja obsługi / User Manual

Packaging contents



Main Studio Box, Light Board, Power supply, Background (6 Colors: Black, White, Orange, Red, Green, Blue), Soft Cloth

Technical specification

Model: PU5060
LED quantity: 2 x 60PCS
Light board: 2PCS
Color temperature: 5500K
Input: AC 110-240V 1.3A
Output: 12V 3A
Output power: 36W
Background: Black, White, Orange, Red, Green, Blue
Size: 60x60x60cm / 24x24x24inch

About product

Portable studio is designed for portability specially. It suits for shooting small subjects and will work excellent everywhere and anytime. But the lighting source quantity and variety were limited due to its size and portability. It is recommended to be used as a temporary studio with excellent easy-to-use feature and premium portability. Studio product must be connected with 12V 2-3A power adapter before using, watch out to use proper power adapter in case of fatal damage to the LED light chips.

Photography guidelines

1. Turn off the HDR function of the camera.
2. Turn off the original color display of your iPhone.
3. Tap the screen lightly to display the logo of small sun. Slide the small sun to adjust the brightness which is equivalent to the digital camera exposure compensation function.

WARNING! THE DEVICE MUST NOT BE DISPOSED OF WITH HOUSEHOLD WASTE.



This symbol indicates that this product must not be disposed of with household waste, according to the EU and your national law. In order to prevent potential damage to the environment or health, the used product must be recycled. In accordance with current legislation, unusable electrical and electronic devices must be collected separately at the designated facilities for recycling, acting on the basis of applicable environmental standards.

Information about used electrical and electronic equipment

The main goal of European and national law regulations is to reduce the amount of waste produced from used electrical and electronic equipment, to ensure an appropriate level of collection, recovery and recycling of used equipment, and to increase public awareness of its harmfulness to the environment, at each stage of use of electrical and electronic equipment. Therefore, it should be pointed out that households play a key role in contributing to reuse and recovery, including recycling of used equipment. The user of electrical and electronic equipment – intended for households – is obliged to return it to authorized collector after its use. However, it should be remembered that products classified as electrical or electronic equipment should be disposed of at authorized collection points.

Operation



1



2



3



4



5



6

1. Remove the light box from its packaging.
2. Gently unfold it.
3. Place the LED light bars inside the light box.
4. Place the background of your choice inside and fold the light box, connecting the individual walls with hook-and-loop fasteners.
5. Connect the light box to the power source using the included power supply unit, taking necessary precautions.
6. Start taking photos or videos using the opening in the side or top wall of the light box.

Zawartość opakowania



Namiot bezcieniowy, belki oświetleniowe, zasilacz, tła (6 kolorów: czarny, biały, pomarańczowy, czerwony, zielony, niebieski), miękka szmatka

Specyfikacja techniczna

Model: PU5060

Diody LED: 2 x 60 szt.

Belki oświetleniowe: 2 szt.

Temperatura barwowa: 5500K

Zasilanie wejściowe: AC 110-240V, 1,3A

Zasilanie wyjściowe: 12V, 2-3A

Moc: 36W

Tła: czarne, białe, pomarańczowe, czerwone, zielone, niebieskie

Wymiary: 60x60x60cm

O produkcie

Produkt został zaprojektowany specjalnie z myślą o mobilności. Nadaje się do fotografowania małych obiektów i doskonale sprawdza się zawsze i wszędzie. Jednak ilość i różnorodność źródeł światła została ograniczona ze względu na jego rozmiar i mobilność. Zaleca się używanie go jako tymczasowego studia fotograficznego. Produkt musi być podłączony do zasilacza 12V, 2-3A, więc przed użyciem należy upewnić się co do parametrów zasilacza, czego zaniechanie może doprowadzić do uszczerbku na zdrowiu. Zaleca się korzystanie z zasilacza dołączonego do produktu.

Porady fotograficzne.

1. Wyłącz funkcję HDR w aparacie.
2. Wyłącz funkcję "Original color display" w iPhone.
3. Dotknij lekko ekranu, aby wyświetlić ikonę "małego słońca". Przesuń ikonę, aby dostosować jasność, co jest odpowiednikiem funkcji kompensacji ekspozycji aparatu cyfrowego.

UWAGA! URZĄDZENIA NIE WOLNO WYRZUCAĆ DO ODPADÓW DOMOWYCH.



To oznaczenie oznacza, że produkt nie może być wyrzucany razem z odpadami domowymi w całej UE. W celu zapobiegnięcia potencjalnym szkodom dla środowiska lub zdrowia, zużyty produkt należy poddać recyklingowi. Zgodnie z obowiązującym prawem, nie nadający się do użycia sprzęt elektryczny i elektroniczny należy zbierać osobno, w specjalnie do tego celu wyznaczonych punktach zbierania zużytego sprzętu, celem ich przetworzenia i ponownego wykorzystania na podstawie obowiązujących norm ochrony środowiska.

Informacja o zużytym sprzęcie elektrycznym i elektronicznym

Głównym celem regulacji europejskich oraz krajowych jest ograniczenie ilości odpadów powstałych ze zużytego sprzętu elektrycznego i elektronicznego, zapewnienie odpowiedniego poziomu jego zbierania, odzysku i recyklingu oraz zwiększenie świadomości społecznej o jego szkodliwości dla środowiska naturalnego, na każdym etapie użytkowania sprzętu elektrycznego i elektronicznego. W związku z powyższym należy wskazać, iż gospodarstwa domowe spełniają kluczową rolę w przyczynianiu się do ponownego użycia i odzysku, w tym recyklingu zużytego sprzętu. Użytkownik sprzętu przeznaczonego dla gospodarstw domowych jest zobowiązany po jego zużyciu do oddania zbierającemu zużyty sprzęt elektryczny i elektroniczny. Należy jednak pamiętać, aby produkty należące do grupy sprzętu elektrycznego lub elektronicznego utylizowane były w uprawnionych do tego punktach zbiórki.

Obsługa



1



2



3



4



5



6

1. Wyjąć namiot bezcieniowy z opakowania.
2. Delikatnie rozłożyć.
3. Umieścić belki oświetleniowe LED w namiocie.
4. Umieścić wewnątrz wybrane tło i złożyć namiot, łącząc poszczególne ściany z pomocą rzepów.
5. Podłączyć namiot bezcieniowy do źródła zasilania za pomocą dołączonego zasilacza, zachowując zasady ostrożności.
6. Rozpocząć robienie zdjęć lub filmów z wykorzystaniem otworu w bocznej lub górnej ścianie namiotu.